



# PSFL-2

## PUMP STAND KIT PLASTIC FIBERWOUND

**FIGURE #1**




**FIGURE #2**




- INSTALL PUMPSTAND LEG (390.0179), TO THE TANK DOME, BY ROTATING CLOCKWISE UNTIL HAND TIGHT.
- INSTALL AIR VALVE EXTENSION (310.0011), TO THE AIR VALVE, BY ROTATING THE COLLAR CLOCKWISE UNTIL HAND TIGHT.
- SEE FIGURE #4 FOR CORRECT ASSEMBLY. AIR VALVE EXTENSION POSITIONED AS SHOWN.

**FIGURE #3**



- INSTALL RUBBER CAPS (390.0182), TO THE PUMPSTAND, BY PUSHING ONTO LEGS.

**FIGURE #4**



- POSITION ASSEMBLY FROM FIGURE #3 ONTO POSTS OF PUMPSTAND LEG #390.0179.
- INSTALL (4), FOUR, THREAD FORMING SCREWS # 390.0181 THROUGH THE PUMPSTAND, INTO THE PUMPSTAND LEG.