



**E01**




POS.	CODE	DESCRIPTION	QTY
E01-1	A10800	CRANKCASE	1
E01-2	A08704	OIL SEAL	1
E01-3	A08544	ENGINE OIL SENSOR	1
E01-4	A08545	RUBBER PLUG	1
E01-5	A08615	OIL ROTECTOR	1
E01-6	A08968	BOLT	1
E01-7	A08546	FLAT WASHER	2
E01-8	A09104	DRAIN PLUG BOLT	2
E01-9	A08924	WIRE CLIP	1
E01-10	A08547	GOVERNOR ARM	1
E01-11	A08726	OIL SEAL	1
E01-12	A08951	COTTER PIN	1
E01-13	A08485	NUT	1
E01-14	A08496	BOLT	2
E01-15	A08548	FLAT WASHER	1
E01-16	A08549	DEEP GROOVE BALL BEARING	1

**E02**




POS.	CODE	DESCRIPTION	QTY
E02-1	A10777	CRANKCASE COVER	1
E02-2	A08305	CRANKCASE GASKET	1
E02-3	A10507	ENGINE OIL PLUG	1
E02-4	A10508	OIL DIPSTICK	1
E02-5	A08550	POSITION PIN	2
E02-6	A08551	BOLT	7
E02-7	A08552	DEEP GROOVE BALL BEARING	1
E02-8	A08730	GOVERNOR GEAR	1
E02-9	A08704	OIL SEAL	1
E02-10	A08549	DEEP GROOVE BALL BEARING	1

**E03**




POS.	CODE	DESCRIPTION	QTY
E03-1	A10881	CYLINDER HEAD GASKET	1
E03-2	A08307	CYLINDER HEAD CONER	1
E03-3	A08308	CYLINDER HEAD COVER GASKET	1
E03-4	A12703	BREATHER TUBE	1
E03-5	A08309	CYLINDER HEAD COVER BOLT	1
E03-6	A08310	BOLT GASKET + WASHER	1
E03-7	A12684	STUD BOLT	2
E03-8	A10517	STUD BOLT	2
E03-9	A08557	POSITION PIN	2
E03-10	A08311	CYLINDER HEAD BOLT	4
E03-11	A11068	SPARK PLUG	1
E03-12	A08312	CYLINDER HEAD	1

**E04**




POS.	CODE	DESCRIPTION	QTY
E04-1	A10810	CRANKSHAFT ASSEMBLY	1
E04-4	A10673	BALANCING SHAFT ASSEMBLY	1

**E05**




POS.	CODE	DESCRIPTION	QTY
E05-1	A11052	PISTON RING SET	1
E05-2	A11044	PISTON	1
E05-3	A08314	PISTON PIN	1
E05-4	A08410	PISTON PIN CLIP	2
E05-5	A11148	CONNECTING ROD	1

**E06**




POS.	CODE	DESCRIPTION	QTY
E06-1	A10735	CAMSHAFT ASSEMBLY	1
E06-4	A08316	VALVES SET	1
E06-5	A08317	VALVE SPRING	2
E06-6	A08318	EXHAUST VALVE RETAINER	1
E06-7	A08319	VALVE ROTATOR	1
E06-8	A08320	SEAL GUIDE	1
E06-9	A08321	VALVE SPRING RETAINER	1
E06-10	A08444	VALVE TAPPET	2
E06-11	A08430	VALVE LIFTER	2
E06-12	A08972	LIFTER STOPPER PLATE	1
E06-13	A08459	ROCKSHAFT BOLT	2
E06-14	A08463	ROCKER VALVE	2
E06-15	A08461	VALVE ADJUSTING NUT	2
E06-16	A08462	VALVE LOCK NUT	2
E06-17	A08322	VALVE SPRING SEAT	1

**E07**



POS.	CODE	DESCRIPTION	QTY
E07-1	A08613	BOLT	3
E07-2	A13076	RECOIL STARTER ASSEMBLY	1


**E08**



POS.	CODE	DESCRIPTION	QTY
E08-1	A13016	SHROUD	1
E08-2	A08559	CYLINDER BODY SHROUD	1
E08-3	A08968	BOLT	1
E08-4	A08968	BOLT	5
E08-5	A11245	STOP ENGINE SWITCH	1
E08-6	A10535	WIRE CLIP	1




**E09**




POS.	CODE	DESCRIPTION	QTY
E09-1	A10741	CARBURETOR ASSEMBLY	1
E09-2	A10537	AIR CLEANER SEAL GASKET	1
E09-3	A08472	CARBURETOR SEAL GASKET	1
E09-4	A08480	CARBURETOR INSULATOR PLATE	1
E09-5	A08562	INLET GASKET	1

**E10**




POS.	CODE	DESCRIPTION	QTY
E10-1	A08431	FLYWHEEL NUT	1
E10-2	A08564	STARTER PULLEY	1
E10-3	A08565	IMPELLER	1
E10-4	A10846	FLYWHEEL	1
E10-6	A08937	BOLT	2
E10-8	A12656	IGNITION COIL	1

**E11**




POS.	CODE	DESCRIPTION	QTY
E11-1	A13046	THROTTLE CONTROL ASSEMBLY	1
E11-2	A08568	THROTTLE VALVE RETURNING SPRING	1
E11-3	A08569	GOVERNOR ROD	1
E11-4	A12654	GOVERNOR SPRING	1
E11-5	A08571	GOVERNOR BRACKET	1
E11-6	A08968	BOLT	2
E11-7	A08506	NUT	1
E11-8	A08505	GOVERNOR SUPPORT BOLT	1

**F01**




POS.	CODE	DESCRIPTION	QTY
F01-6	A08767	BOLT	1
F01-13	A13091	AIR FILTER	1
F01-14	A08506	NUT	2
F01-15	A11337	AIR FILTER ELEMENT	1

**F02**




POS.	CODE	DESCRIPTION	QTY
F02-1	A11013	MUFFLER ASSEMBLY	1
F02-2	A10549	MUFFLER GASKET	1
F02-3	A08520	NUT	5
F02-4	A10550	EXHAUST PIPE	1
F02-5	A08663	EXHAUST OUTLET GASKET	1

**F03**




POS.	CODE	DESCRIPTION	QTY
F03-1	A12653	FUEL TANK	1
F03-2	A09932	FUEL STRAINER	1
F03-3	A11333	FUEL TANK COVER	1
F03-4	A09934	FUEL TANK OIL OUTLET	1
F03-5	A10752	COLLAR	2
F03-6	A12704	FUEL TUBE	1
F03-7	A08520	NUT	2
F03-8	A10535	WIRE CLIP	1
F03-9	A10693	BOLT	2

# F61



POS.	CODE	DESCRIPTION	QTY
F61-1	A10996	WATER PUMP JOINT	1
F61-2	A10861	SEAL WASHER	4
F61-3	A10719	BOLT	4
F61-4	A11166	MECHANISM SEAL	1
F61-5	A11324	WATER PUMP JOINT CUSHION	1
F61-6	A10950	WATER PUMP IMPELLER	1
F61-7	A11325	SPACER	2
F61-8	A10749	WHORL CASE	1
F61-9	A11154	SCREW	2
F61-10	A11118	WHORL CASE SEALING RIGN	1
F61-11	A11138	IMPELLER SEAL RING	1
F61-12	A11103	PUMP BODY	1
F61-13	A10714	BOLT	6
F61-14	A11295	SCREW PLUG WASHER	2
F61-15	A11076	THREAD PLUG	2
F61-16	A10692	BOLT	6
F61-17	A10959	WATER INLET	1
F61-18	A10902	INLET WATER GASKET	1
F61-19	A10911	OUTLET GASKET	1
F61-20	A11033	WATER OUTLET	1
F61-21	A10692	BOLT	4
F61-22	A11003	GENERAL FLAT KEY	1
F61-23	A11274	SEAL WASHER	1
F61-24	A10718	HEXAGONAL HEAD BOLT	1
F61-25	A10930	HOSE HOOP	3
F61-26	A11182	PORCELAIN SEAL	1
F61-27	A11092	WATER PUMP ASSEMBLY	1
F61-28	A10985	HOSE JOINT	2
F61-29	A10971	HOSE INTERFACE	2


# F61



POS.	CODE	DESCRIPTION	QTY
F61-30	A11130	HOSE JOINT SEAL RING	2
F61-31	A10793	COVER, FILTER	1
F61-32	A10838	FILTER	1
F61-33	A11322	FLYWEIGHT	1
F61-34	A11323	FILM CLAMP	1
F61-35	A10720	BOLT	1



**F04**



POS.	CODE	DESCRIPTION	QTY
F04-1	A10852	ENGINE FRAME ASSEMBLY	1
F04-2	A08494	BOLT	4
F04-3	A11185	ENGINE FRAME SHOCK ABSORPTION SEAT	4
F04-5	A10717	BOLT	4
F04-6	A08485	NUT	6
F04-7	A10716	BOLT	2